

## Mitel Embedded Voicemail Quick Reference Guide

### VOICEMAIL SYSTEM ACCESS AND MAILBOX NUMBER

The voicemail extension is pre-programmed on the voicemail key. Use this key to access the voicemail system. Mailbox numbers are the same as the system assigned phone extension.

### CALLING THE VOICEMAIL SYSTEM FOR THE FIRST TIME

1. Lift the handset (or use handsfree dialing).
2. Press the Voicemail key. The system prompts you for your passcode. The default passcode is 1111.

*A user tutorial will automatically activate. This tutorial will guide you through your first mailbox session – setting a passcode, recording a personal greeting, and recording your name for the company directory.*

### ACCESSING VOICEMAIL

*To access your mailbox if you do not have a new message*

1. Press Voicemail key or dial the voicemail extension
2. Enter passcode

*To access voicemail from outside the office flashing*

1. Dial your company's main number.
2. When the Auto Attendant (Company Greeting) plays, press \*
3. Enter your mailbox number
4. Enter your passcode



*To access voicemail if your message light is flashing*

1. Lift the handset
2. Press the flashing Message button
3. Enter passcode

*To access a General Mailbox when indication light is flashing*

1. Lift the Handset
2. Press the flashing Message key
3. Enter the passcode



### TRANSFER A CALL DIRECTLY TO A VOICEMAIL BOX

*To transfer a call to a voicemail box:*

1. Press Trans/Conf
2. Press \*
3. Enter the extension or mailbox number
4. Hang up immediately

### LISTENING TO VOICEMAIL MESSAGES

Press  to Play the messages

### WHILE LISTENING TO A MESSAGE



Press 1 to pause the message



Press 8 to skip to the next message



Press \* to rewind the message 5 seconds



Press # to fast forward the message 5 seconds

### MESSAGE OPTIONS

*After a message has finished playing, you have the following options:*



Press 7 to re-play the message



Press 5 to keep or save the message



Press 2 to send a reply message



Press 3 to discard or delete the message

When finished, press 9 to send the response



Press 4 to forward the message to another mailbox. Messages can be forwarded with or without comments.



Pressing the \* key immediately after discarding a message will recover the discarded message.